



3DLPrinter-HD 2.0+



To unpack 3DLPrinter-HD 2.0+

What does it take to unpack 3DLPrinter-HD 2.0+:

- A large scissors or an instrument for cutting the strap that wraps around the box.
- An instrument for cutting the scotch.
- A screwdriver and pliers to remove the staples.
- Leather gloves for protect your hands.

PRECAUTIONS

We recommend the use of suitable gloves to avoid accidental injury while you open the package.

Please note that all products used for packaging must be disposed of in full compliance with environmental standards in force at national, regional or local level.

In this regard, we refer to the user the responsibility of disposing of waste, he should inquire at the specific organizations duly authorized, in accordance with EC regulations in force, among which particular mention is made:

- Community Directive 2006/12/EC (waste disposal);
- Community Directive 87/101/EC (hazardous waste disposal);
- Community Directive 75/439/EC (disposal of waste oils).

These directives are binding only at European level, and are subject to changes or updates based on technological advances made over the years. The editions listed are those in effect at the time of writing of this manual. You must verify at reasonable intervals that they are still relevant today.

Of course, in countries where the European Community legislation is not applicable, they must be complied with similar ecological provisions valid locally.

STRICTLY follow these steps

After you cut with an instrument for cutting, or with a large scissors, the strap that wraps around the case, perform the following steps (in the same order):



1. Remove the scotch tape, open the package and remove the boxes containing the accessories.



2. With a screwdriver or similar tool, if necessary use a pair of pliers, remove the staples that hold the cardboard (there are more than one staples on each side).



3. Remove, pulling from above, the protective cardboard.



4. Remove the masking tape that locks the handles.



5. In two people, grasp the handles being careful to balance the printer, lift both sides at the same time and place the printer on the work surface.



To use, place **3DLPrinter-HD 2.0+** on a solid, flat and stable surface.

6. Pull away the handles and carefully remove the protective nylon to protect the printer (note that these protections can be dangerous for children if used as a game, because they can cause suffocation).



In the box containing the accessories there is the DVD with the documentation and programs, in the inside cover is present the EC declaration in addition to the serial number.

Verify the presence of accessories included in the package itself and identify their use by consulting the manual "**Installation, Use and Maintenance**" (see p. 12 and later).

Carefully read the manual "**Installation, Use and Maintenance**" before attempting to operate **3DLPrinter-HD 2.0+**.



Robot Factory S.r.l. - Via Caltana, 59 - 30035 Mirano VE
Tel - Fax:0415770270 Mobile:3387159853 - P.IVA: 03654900277
www.robotfactory.it - robot@robotfactory.it

Robot Factory S.r.l. reserves the right to make changes in specifications, materials and accessories without notice. No warranty is provided beyond that attached to the product. Robot Factory S.r.l. assumes no liability for any incidental or consequential, foreseeable or not, caused by misuse of its products.